

## **SADDLE POLICE ADOPTED AT THE JUNE 21, 2005 SID#5 MEETING**

Regarding the specifications for saddles used in tapping water mains:

After full and careful discussion the following resolution was duly moved by Trustee Morrison and seconded by Trustee Bolton:

**BE IT RESOLVED**, by the Board of Trustees of Sanitary and Improvement District No. 5 of Cass County, Nebraska, that the specifications for saddles and stops to be used in tapping water mains and the procedures for such tapping are hereby defined:

Tapping Saddle: Smith Blair #317 or its equivalent

Corp Stop: Mueller #H15008 (Flair or Comp. Ball Type – Minneapolis Pattern) or its equivalent

Curb Stop: Mueller #B2155 (Flair or Comp. Ball Type – Minneapolis Pattern) or its equivalent

Stop Box: Mueller#5615 (Buried a minimum of five (5) feet with stationary rod – Minneapolis Pattern) or its equivalent.

Procedure: 1) Call Operator to obtain size of water line, type and location  
2) Create installation map  
3) Call Operator for inspection of the tap.

Prior to arrival of operator:

- 1) Wash down pipe with chlorine and install saddle and corp stop
- 2) Chlorinate corp stop prior to tapping
- 3) Chlorinate tapping blade prior to coating with cutting lubricant
- 4) Tap pipe when cleared to do so by Operator (system has been isolated and pressure relieved on 10-inch or larger lines.)
- 5) Install curb stop and stop box. Inoculate service line with chlorine.
- 6) Complete installation by blowing off new service line until clear water is observed.
- 7) Close curb stop.

On roll call on the foregoing motion, the following Trustees voted aye: John Bolton, Kurt Meisinger, Janet McCartney, W. L. Morrison, Jr., and John Sandoz. Voting nay were the following Trustees: none. The Chairman then declared said resolution to be duly carried and adopted.